

# Physical installation instruction

## Pro-B2 Control unit / 1-phase (4,5-10 kW electric heaters)

Affixing the sensor to the ceiling:  
distance from heater frame 100–400 mm

The temperature sensor should be installed no less than 1000 mm from an undirected air vent income, or less than 500 mm from a directed air vent.

